




SERVICE MANUAL

# M DESIGN, INVERTER SERIES

---

2017 SERVICE MANUAL





|   |           |
|---|-----------|
| <b>1. Safety Precautions .....</b>  | <b>1</b>  |
| 1. In case of Accidents or Emergency                                      |           |
| 2. Pre-Installation and Installation                                      |           |
| 3. Operation and Maintenance  |           |
| <b>2. Specifications .....</b>  | <b>3</b>  |
| 1. Model Reference  |           |
| 2. Electrical Wiring Diagrams   |           |
| <b>3. Product Features .....</b>  | <b>9</b>  |
| 1. Operation Modes and Functions  |           |
| <b>4. Maintenance and Disassembly .....</b>                               | <b>17</b> |
| 1. Maintenance  |           |
| 2. Disassembly  |           |
| <b>5. Troubleshooting .....</b>   | <b>56</b> |
| 1. Safety Caution   |           |
| 2. General Troubleshooting  |           |
| 3. Error Diagnosis and Troubleshooting Without Error Code                 |           |
| 4. Quick Maintenance by Error Code  |           |
| 5. Troubleshooting by Error Code  |           |
| <b>Appendix .....</b>   | <b>82</b> |
| i) Temperature Sensor Resistance Value Table for T1,T2,T3 and T4 (°C - K) |           |
| ii) Temperature Sensor Resistance Value Table for TP (°C - K)             |           |



---

# Safety Precautions

## Contents

|    |   |   |
|----|---|---|
| 1. | In Case of Accidents or Emergency ..... | 2 |
| 2. | Pre-Installation.....                   | 2 |
| 3. | Operation and Maintenance.....          | 2 |

To prevent personal injury, or property or unit damage, adhere to all precautionary measures and instructions outlined in this manual. Before servicing a unit, refer to this service manual and its relevant sections.

Failure to adhere to all precautionary measures listed in this section may result in personal injury, damage to the unit or to property, or in extreme cases, death.

**!** **WARNING** indicates a potentially hazardous situation which if not avoided could result in serious personal injury, or death.

**!** **CAUTION** indicates a potentially hazardous situation which if not avoided could result in minor or moderate personal injury, or unit damage.

## 1. In case of Accidents or Emergency

### **!** **WARNING**

- If a gas leak is suspected, immediately turn off the gas and ventilate the area if a gas leak is suspected before turning the unit on.
- If strange sounds or smoke is detected from the unit, turn the breaker off and disconnect the power supply cable.
- If the unit comes into contact with liquid, contact an authorized service center.
- If liquid from the batteries makes contact with skin or clothing, immediately rinse or wash the area well with clean water.
- Do not insert hands or other objects into the air inlet or outlet while the unit is plugged in.
- Do not operate the unit with wet hands.
- Do not use a remote controller that has previously been exposed to battery damage or battery leakage.



- Clean and ventilate the unit at regular intervals when operating it near a stove or near similar devices.
- Do not use the unit during severe weather conditions. If possible, remove the product from the window before such occurrences.

## 2. Pre-Installation and Installation

### **!** **WARNING**

- Use this unit only on a dedicated circuit.
- Damage to the installation area could cause the unit to fall, potentially resulting in personal injury, property damage, or product failure.
- Only qualified personnel should disassemble, install, remove, or repair the unit.
- Only a qualified electrician should perform electrical work. For more information, contact your dealer, seller, or an authorized Midea service center.



### **!** **CAUTION**

- While unpacking be careful of sharp edges around the unit as well as the edges of the fins on the condenser and evaporator.

## 3. Operation and Maintenance



### **!** **WARNING**

- Do not use defective or under-rated circuit breakers.
- Ensure the unit is properly grounded and that a dedicated circuit and breaker are installed.
- Do not modify or extend the power cable. Ensure the power cable is secure and not damaged during operation.
- Do not unplug the power supply plug during operation.
- Do not store or use flammable materials near the unit.
- Do not open the inlet grill of the unit during operation.
- Do not touch the electrostatic filter if the unit is equipped with one.
- Do not block the inlet or outlet of air flow to the unit.
- Do not use harsh detergents, solvents, or similar items to clean the unit. Use a soft cloth for cleaning.
- Do not touch the metal parts of the unit when removing the air filter as they are very sharp.
- Do not step on or place anything on the unit or outdoor units.
- Do not drink water drained from the unit
- **!** **CAUTION** Avoid direct skin contact with water drained from the unit.
- Use a firm stool or step ladder according to manufacturer procedures when cleaning or maintaining the unit.

- Do not install or operate the unit for an extended period of time in areas of high humidity or in an environment directly exposing it to sea wind or salt spray.
- Do not install the unit on a defective or damaged installation stand, or in an unsecure location.
- Ensure the unit is installed at a level position
  - Do not install the unit where noise or air discharge created by the outdoor unit will negatively impact the environment or nearby residences.

- Do not expose skin directly to the air discharged by the unit for prolonged periods of time.
- Ensure the unit operates in areas water or other liquids.
- Ensure the drain hose is installed correctly to ensure proper water drainage.
- When lifting or transporting the unit, it is recommended that two or more people are used for this task.
- When the unit is not to be used for an extended time, disconnect the power supply or turn off the breaker.

---

# Specifications

## Contents

|     |                                 |   |
|-----|---------------------------------|---|
| 1.  | Model Reference.....            | 4 |
| 2.  | Electrical Wiring Diagrams..... | 5 |
| 2.1 | Indoor Unit<br>.....            | 5 |
| 2.2 | Outdoor Unit<br>.....           | 7 |

---

## 1. Model Reference

Refer to the following table to determine the specific indoor and outdoor unit model number of your purchased equipment.


| Indoor Unit Model | Outdoor Unit Model | Capacity (Btu) | Power Supply               |
|-------------------|--------------------|----------------|----------------------------|
| ACP-09CH25AEMI/I  | ACP-09CH25AEMI/O   | 9K             | 220-240V~, 50Hz,<br>1Phase |
| ACP-12CH35AEMI/I  | ACP-12CH35AEMI/O   | 12K            |                            |
|                   |                    |                |                            |
| ACP-18CH50AEMI/I  | ACP-18CH50AEMI/O   | 18K            |                            |
| ACP-24CH70AEMI/I  | ACP-24CH70AEMI/O   | 24K            |                            |



## 2. Electrical Wiring Diagrams

### 2.1 Indoor unit


| Abbreviation    | Paraphrase                                       |
|-----------------|--|
| Y/G             | Yellow-Green Conductor                           |
| ION             | Positive and Negative Ion Generator              |
| CAP             | Capacitor  |
| PLASMA          | Electronic Dust Collector                        |
| to CCM Comm.Bus | Central Controller (for CAC)                     |
| X Y E           | 485 Communication Line                           |
| L               | LIVE   |
| N               | NEUTRAL  |
| Heater          | The Electric Heating Belt of Indoor Unit         |
| T1              | Indoor Room Temperature                          |
| T2              | Coil Temperature of Indoor Heat Exchanger Middle |
| T3              | Coil Temperature of Condenser                    |
| T4              | Outdoor Ambient Temperature                      |
| TH              | Compressor Suction Temperature                   |
| EEV             | Electric Expansive Valve                         |
| TP              | Compressor Discharge Temperature                 |
| T2B             | Coil Temperature of Indoor Heat Exchanger Outlet |



## 2.2 Outdoor Unit

| Abbreviation | Paraphrase                     |
|--------------|--------------------------------|
| 4-WAY        | Gas Valve Assembly/4-WAY VALVE |
| AC-FAN       | Alternating Current FAN        |
| DC-FAN       | Direct Current FAN             |
| CT1          | AC Current Detector            |
| COMP         | Compressor                     |
| L-PRO        | Low Pressure Switch            |
| H-PRO        | High Pressure Switch           |

ACP-09CH25AEMI/O; ACP-12CH35AEMI/O.; ACP-18CH50AEMI/O





# Product Features

## Contents

|           |  |           |
|-----------|--|-----------|
| <b>1.</b> | <b>Operation Modes and Functions .....</b> | <b>10</b> |
| 1.1       | Abbreviation.....                          | 10        |
| 1.2       | Safety Features .....                      | 10        |
| 1.3       | Display Function .....                     | 11        |
| 1.4       | Fan Mode .....                             | 11        |
| 1.5       | Cooling Mode .....                         | 11        |
| 1.6       | Heating Mode .....                         | 12        |
| 1.7       | Auto-mode.....                             | 12        |
| 1.8       | Drying Mode .....                          | 12        |
| 1.9       | Forced Operation Function .....            | 12        |
| 1.10      | Sleep Function .....                       | 13        |
| 1.11      | Auto-Restart Function.....                 | 13        |
| 1.12      | Refrigerant Leakage Detection .....        | 13        |
| 1.13      | 8°C Heating(Optional) .....                | 13        |
| 1.14      | Self Clean(Optional).....                  | 13        |
| 1.15      | Follow Me(Optional) .....                  | 13        |
| 1.16      | Silence (Optional) .....                   | 13        |

|                          |    |
|--------------------------|----|
| .....                    | 13 |
| 1.17 Information Inquiry |    |
| .....                    | 13 |

# 1. Operation Modes and Functions

## 1.1 Abbreviation

Unit element abbreviations

| Abbreviation | Element                          |
|--------------|----------------------------------|
| T1           | Indoor room temperature          |
| T2           | Coil temperature of evaporator   |
| T3           | Coil temperature of condenser    |
| T4           | Outdoor ambient temperature      |
| TS           | Set temperature                  |
| TP           | Compressor discharge temperature |

## 1.2 Safety Features

### Compressor three-minute delay at restart

Compressor functions are delayed for up to one minute upon the first startup of the unit, and are delayed for up to three minutes upon subsequent unit restarts.

### Automatic shutoff based on compressor top temperature

The unit ceases operation when the compressor top temperature exceeds a pre-determined threshold. The unit will restart after the temperature guard of the compressor top restarts.

### Automatic shutoff based on discharge temperature

If the compressor discharge temperature exceeds 115°C for five seconds, the compressor ceases operation.

### Automatic shutoff based on fan speed

If the indoor fan speed registers below 300RPM for an extended period of time, the unit ceases operation and the corresponding error code is displayed on the indoor unit.

### Inverter module protection

The inverter module has an automatic shutoff mechanism based on the units current, voltage, and temperature. If automatic shutoff is initiated, the corresponding error code is displayed on the indoor unit and the unit ceases operation.

### Indoor fan delayed operation

- When the unit starts, the louver is automatically activated and the indoor fan will operate after a period of 7 seconds.
- If the unit is in heating mode, the indoor fan is regulated by the anti-cold wind function.

### Compressor preheating

Preheating is automatically activated when T4 sensor is lower than 3°C.

### Sensor redundancy and automatic shutoff

- If one temperature sensor malfunctions, the air conditioner continues operation and displays the corresponding error code, allowing for emergency use.
- When more than one temperature sensor is malfunctioning, the air conditioner ceases operation.

### Refrigerant leakage detection

This function is active only when cooling mode is selected. It will detect if the compressor is being damaged by refrigerant leakage or by compressor overload. This is measured using the coil temperature of evaporator T2 when the compressor is in operation.

## 1.3 Display Function

Unit display functions



| Function  | Display               |
|---|-----------------------|
| Temperature   | Set temperature value |
| Temperature (fan and Drying mode)                         | Room temperature      |
| Activation of Timer ON, Fresh, Swing, Turbo, or Silent    | (3s)                  |
| Cancellation of Timer OFF, Fresh, Swing, Turbo, or Silent | 00<br>(3s)            |
| Defrost   | DF                    |
| Warming in heating mode                                   | dF                    |
| Self-clean (available on select units only)               | cF                    |
| Heating in room temperature under 8°C                     | SC                    |
|   | FP                    |

## 1.4 Fan Mode

When fan mode is activated:

- The outdoor fan and compressor are stopped.
- Temperature control is disabled and no temperature setting is displayed.
- The indoor fan speed can be set to high, med, low, or auto.
- The louver operations are identical to those in cooling mode.
- Auto fan: In fan-only mode, AC operates the same as auto fan in cooling mode with the temperature set at 24°C.

## 1.5 Cooling Mode

### 1.5.1 Compressor Control

$\Delta T$  is the programmed parameter of temperature compensation.

- When  $T1 - T_s < \Delta T - 2^\circ\text{C}$ , the compressor ceases operation.
- When  $T1 - T_s > \Delta T - 0.5^\circ\text{C}$ , the compressor continues operation.
- When the AC is operating in mute mode, the compressor operates at a low frequency.
- When the current exceeds the preset value, the current protection function activates and the compressor ceases operation.

### 1.5.2 Indoor Fan Control

- In cooling mode, the indoor fan operates continuously. The fan speed can be set to high, medium, low, or auto.
- If the compressor ceases operations when the configured temperature is reached, the indoor fan motor operates at the minimum or configured speed.

### 1.5.3 Outdoor Fan Control

- For ACP-18CH50AEMI/I & MSAFBU-24HRFN1-QRD0GW, The outdoor unit will be run at different fan speed according to T4.
- For ACP-09CH25AEMI/I, MSAFBU-12HRDN1-QRD0GW and MSAFCU-18HRFN1-QRD0GW(S1), The outdoor unit will be run at different fan speed according to T4 and compressor frequency.
- For different outdoor units, the fan speeds are different.

### 1.5.4 Condenser Temperature Protection



When condenser temperature is more than setting value, the compressor will stop.

### 1.5.5 Evaporator Temperature Protection

When evaporator temperature drops below a configured value, the compressor and outdoor fan ceases operations.

## 1.6 Heating Mode

### 1.6.1 Compressor Control

$\Delta T$  is the programmed parameter of temperature compensation.

- When  $T1-Ts > \Delta T$ , the compressor ceases operation.
- When  $T1-Ts < \Delta T - 1.5^\circ C$ , the compressor continues operation.
- When the AC is operating in mute mode, the compressor operates at a low frequency.
- When the current exceeds the preset value, the current protection function activates and the compressor ceases operation.

### 1.6.2 Indoor Fan Control:

- When the compressor is on, the indoor fan can be set to high/medium/low/auto.
- When indoor unit coil temperature is low, the anti-cold air function will start and indoor fan motor will run at low speed, the speed can't be changed, when the temperature is lower than setting value, the indoor fan motor will stop.
- When the indoor temperature reaches the setting temperature, the compressor will stop, the indoor fan motor will run at the minimum speed or setting speed. (The anti-cold air function is valid).

### 1.6.3 Outdoor Fan Control:

- For ACP-18CH50AEMI/I & ACP-24CH70AEMI/I, the outdoor unit will be run at different fan speed according to T4.
- For ACP-09CH25AEMI/I, ACP-12CH35AEMI/I and ACP-18CH50AEMI/I, the outdoor unit will be run at different fan speed according to T4 and compressor frequency.
- For different outdoor units, the fan speeds are different.

### 1.6.4 Defrosting mode

- For ACP-09CH25AEMI/I, ACP-24CH70AEMI/I and ACP-18CH50AEMI/I, the unit enters defrosting mode according to changes in the temperature value of T3, the temperature value of T4 as well as the compressor running time.

- For ACP-18CH50AEMI/I & ACP-24CH70AEMI/I, the unit enters defrosting mode according to changes in the temperature value of T3 as well as the compressor running time.
- In defrosting mode, the compressor continues to run, the indoor and outdoor motor will cease operation, the defrost light of the indoor unit will turn on, and the "df" symbol is displayed.
- If any one of the following conditions is satisfied, defrosting ends and the machine switches to normal heating mode:
  - T3 rises above  $TCDE1^\circ C$ .
  - T3 maintained above  $TCDE2^\circ C$  for 80 seconds.
  - For ACP-09CH25AEMI/I, ACP-12CH35AEMI/I and ACP-18CH50AEMI/I, unit runs for 15 minutes consecutively in defrosting mode.
  - For ACP-18CH50AEMI/I & ACP-24CH70AEMI/I, unit runs for 10 minutes consecutively in defrosting mode.

### 1.6.5 Evaporator Temperature Protection

When the evaporator temperature exceeds a preset protection value, the compressor stops.

## 1.7 Auto-mode

- This mode can be selected with the remote controller and the setting temperature can be changed between  $17^\circ C \sim 30^\circ C$ .
- In auto mode, the machine selects cooling, heating, or fan-only mode on the basis of  $\Delta T$  ( $\Delta T = T1 - Ts$ ).

| $\Delta T$                                | Running mode |
|---|--------------|
| $\Delta T > 2^\circ C$                    | Cooling      |
| $-2^\circ C \leq \Delta T \leq 2^\circ C$ | Fan-only     |
| $\Delta T < -2^\circ C$                   | Heating*     |

Heating\*: In auto mode, cooling only models run the fan

- The louver operates same as in relevant mode.
- If the machine switches mode between heating and cooling, the compressor will keep stopping for certain time and then choose mode according to T1-Ts.
- If the setting temperature is modified, the machine will choose running function again.

## 1.8 Drying mode

- Indoor fan speed is fixed at breeze and can't be changed. The louver angle is the same as in cooling mode.

- All protections are active and the same as that in cooling mode.

## 1.9 Forced operation function

- Forced cooling mode:

The compressor and outdoor fan continue to run and the indoor fan runs at low speed. After running for 30 minutes, the AC will switch to auto mode with a preset temperature of 24°C.

- Forced auto mode:

Forced auto mode operates the same as normal auto mode with a preset temperature of 24°C.

- The unit exits forced operation when it receives the following signals:
  - Switch on
  - Switch off
  - Timer on
  - Timer off
- Changes in:
  - mode
  - fan speed
  - sleeping mode
  - Follow me

## 1.10 Sleep function

- The sleep function is available in cooling, heating, or auto mode.
- The operational process for sleep mode is as follows:
  - When cooling, the temperature rises 1°C (to not higher than 30°C) every hour. After 2 hours, the temperature stops rising and the indoor fan is fixed at low speed.
  - When heating, the temperature decreases 1°C (to not lower than 17°C) every hour. After 2 hours, the temperature stops decreasing and the indoor fan is fixed at low speed. Anti-cold wind function takes priority.
- The operating time for sleep mode is 7 hours, after which, the unit exits this mode and switches off.
- The timer setting is available in this mode.

## 1.11 Auto-Restart function

- The indoor unit has an auto-restart module that allows the unit to restart automatically. The module automatically stores the current settings (not incl

- the swing setting) and, in the case of a sudden power failure, will restore those setting automatically within 3 minutes after power returns.
- If the unit was in forced cooling mode, it will run in this mode for 30 minutes and turn to auto mode with temperature set to 24°C.
- If there is a power failure while the unit is running, the compressor starts 3 minutes after the unit restarts. If the unit was already off before the power failure, the compressor starts 1 minute after the unit restarts.

## 1.1 Refrigerant Leakage Detection

With this new technology, the display area will show "EC" when the outdoor unit detects refrigerant leakage.

## 1.2 8°C Heating(Optional)

In heating mode, the temperature can be set to as low as 8°C, preventing the indoor area from freezing if unoccupied during severe cold weather.

## 1.3 Self clean(Optional)

- If you press "Self Clean" when the unit is in cooling or drying mode:
  - For cooling models, the indoor unit will run in low fan mode for a certain time, then ceases operation.
  - For heat pump models, the indoor unit will run in fan-only mode, then low heat, and finally in fan-only mode.
- Self Clean keeps the indoor unit dry and prevents mold growth.

## 1.4 Follow me(Optional)

- If you press "Follow Me" on the remote, the indoor unit will beep. This indicates the follow me function is active.
- Once active, the remote control will send a signal every 3 minutes, with no beeps. The unit automatically sets the temperature according to the measurements from the remote control.
- The unit will only change modes if the information from the remote control makes it necessary, not from the units temperature setting.
- If the unit does not receive a signal for 7 minutes or you press "Follow Me," the function turns off. The unit regulates temperature based on its own sensor and settings.

## 1.5 Silence (Optional)

---

Press "Silence" on the remote control to enable the SILENCE function. While this function is active, the compressor frequency is maintained at a lower level than F2. The indoor unit will run at faint breeze, which reduces noise to the lowest possible level.

## 1.6 Information Inquiry

- To enter information inquiry status, complete the following procedure within ten seconds:
  - Press LED 3 times.
  - Press SWING 3 times.
- If you are successful, you will hear beeps for two seconds.
- Use the LED and SWING buttons to cycle through information displayed.
- Pressing LED will display the next code in the sequence. Pressing SWING will show the previous.
- The following table shows information codes. The screen will display this code for two seconds, then the information for 25 seconds.

| Displayed code                                     | Explanation                        | Displayed value   | Meaning   | Additional Notes  |
|--|------------------------------------|---|---|---|
| T1<br>T2<br>T3<br>T4<br>Tb<br>TP<br>TH<br>FT<br>Fr | Room temperature                   | -1F,-1E,-1d,-1c,-1b,-1A<br>-19—99<br>A0,A1,...A9<br>b0,b1,...b9<br>c0,c1,...c9<br>d0,d1,...d9<br>E0,E1,...E9<br>F0,F1,...F9 | -25,-24,-23,-22,-21,-20<br>-19—99<br>100,101,...109<br>110,111,...119<br>120,121,...129<br>130,131,...139<br>140,141,...149<br>150,151,...159 | <ol style="list-style-type: none"> <li>All displayed temperatures use actual values.</li> <li>All temperatures are displayed in °C regardless of remote used.</li> <li>T1, T2, T3, T4, and T2B display ranges from -25 to 70 °C. TP display ranges from -20 to 130 °C.</li> <li>The frequency display ranges from 0 to 159HZ.</li> <li>If the actual values exceed or fall short of the defined range, the values closest to the maximum and minimum values will be displayed.</li> </ol> |
|  | Indoor coil temperature            |   |   |   |
|  | Outdoor coil temperature           |   |   |   |
|  | Ambient temperature                |   |   |   |
|  | Outlet temperature of indoor coil  |   |   |   |
|  | Discharge temperature              |   |   |   |
|  | Suction temperature                |   |   |   |
|  | Targeted frequency                 |   |   |   |
|  | Actual frequency                   |   |   |   |
| IF   | Indoor fan speed                   | 0<br>1,2,3,4  | OFF<br>Low speed, Medium speed, High speed, Turbo.  | N/A<br>Used for some large capacity motors.   |
|  |                                    | 14-FF   | Actual fan speed is equal to the display value converted to decimal value and multiplied by 10. This is measured in RPM.                      | Used for some small capacity motors.<br>The display value is 14-FF (hexadecimal). The corresponding fan speed ranges from 200 to 2550RPM.   |
| OF   | Outdoor fan speed                  |   |   |   |
| LA   | EXV opening angle                  | 0-FF  | Actual EXV opening value is equal to the display value converted to decimal value and then multiplied by 2.                                   | -   |
| CT   | Compressor continuous running time | 0-FF  | 0-255 minutes   | If the actual value exceeds or falls short of the defined range, the value closest to the maximum and minimum will be displayed.  |
| ST   | Causes of compressor stop          | 0-99  | For a detailed explanation, contact technical support.  | -   |

| Displayed code | Explanation | Displayed value              | Meaning | Additional Notes |
|----------------|-------------|------------------------------|---------|------------------|
| A0             | Reserved    | 0-FF<br>2-28<br>5-20<br>5-25 | -       | -                |
| A1             |             |                              |         |                  |
| b0             |             |                              |         |                  |
| b1             |             |                              |         |                  |
| b2             |             |                              |         |                  |
| b3             |             |                              |         |                  |
| b4             |             |                              |         |                  |
| b5             |             |                              |         |                  |
| b6             |             |                              |         |                  |
| dL             |             |                              |         |                  |
| A <sub>C</sub> |             |                              |         |                  |
| U <sub>o</sub> |             |                              |         |                  |
| T <sub>d</sub> |             |                              |         |                  |
| dA             |             |                              |         |                  |
| dS             |             |                              |         |                  |
| dT             |             |                              |         |                  |

---

# Maintenance and Disassembly

## Contents

|                                   |           |
|-----------------------------------|-----------|
| <b>1. Maintenance</b>             | <b>18</b> |
| 1.1 First Time Installation Check | 18        |
| 1.2 Refrigerant Recharge          | 20        |
| 1.3 Re-Installation               | 21        |
| 1.3.1 Indoor Unit                 | 21        |
| 1.3.2 Outdoor Unit                | 23        |
| <b>2. Disassembly</b>             | <b>25</b> |
| 2.1 Indoor Unit                   | 25        |
| 2.2 Outdoor Unit                  | 37        |

# 1. Maintenance

## 1.1 First Time Installation Check

Air and moisture trapped in the refrigerant system affects the performance of the air conditioner by:


- Increasing pressure in the system.
- Increasing the operating current.
- Decreasing the cooling or heating efficiency.
- Congesting the capillary tubing due to ice build-up in the refrigerant circuit.
- Corroding the refrigerant system.

To prevent air and moisture from affecting the air conditioners performance, the indoor unit, as well as the pipes between the indoor and outdoor unit, must be leak tested and evacuated.

### Leak test (soap water method)

Use a soft brush to apply soapy water or a neutral liquid detergent onto the indoor unit connections and outdoor unit connections. If there is gas leakage, bubbles will form on the connection.

### Air purging with vacuum pump




---

**Procedure:**

1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
3. Connect the charge hose of Handle Hi connection to the vacuum pump.
4. Fully open the Handle Lo manifold valve.
5. Using the vacuum pump, evacuate the system for 30 minutes.
  - a. Check whether the compound meter indicates -0.1 MPa (14.5 Psi).
    - If the meter does not indicate -0.1 MPa (14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
    - If the pressure does not achieve -0.1 MPa (14.5 Psi) after 50 minutes, check for leakage.
    - If the pressure successfully reaches -0.1 MPa (14.5 Psi), fully close the Handle Lo valve and cease vacuum pump operations.
  - b. Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump.
6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
  - a. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
  - b. Remove the charge hose from the 3-way valve.
7. Fully open the 2- and 3-way valves and tighten the cap of the 3-way valve.



## 1.2 Refrigerant Recharge



Prior to recharging the refrigerant, confirm the additional amount of refrigerant required using the following table:

| Models | Standard length | Max. elevation | Max. length  | Additional refrigerant |
|--------|-----------------|----------------|--------------|------------------------|
| 9k&12k | 5m (16.4ft)     | 10m (32.8ft)   | 25m (82.0ft) | 15g/m (0.16oz/ft)      |
| 18k    | 5m (16.4ft)     | 20m (65.6ft)   | 30m (98.4ft) | 15g/m (0.16oz/ft)      |
| 24k    | 5m (16.4ft)     | 25m (82.0ft)   | 50m (164ft)  | 30g/m (0.32oz/ft)      |


### Procedure:

1. Connect the charge hose to the 3-way service port and then open the 2- and the 3-way valves.
2. Connect the charge hose to the valve at the bottom of the cylinder.
3. If the refrigerant is R410A, invert the cylinder to ensure a complete liquid charge.
4. Open the valve at the bottom of the cylinder and close the check valve on the charge set to purge the air.
5. Place the charging cylinder onto an electronic scale and record the starting weight.
6. Operate the air conditioner in cooling mode.
7. Open the valves (Low side) on the charge set and charge the system with liquid refrigerant.
8. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm), disconnect the charge hose from the 3-way valves service port immediately and turn off the air conditioner before disconnecting the hose.
9. Mount the valve stem caps and the service port.
10. Use a torque wrench to tighten the service port cap to a torque of 18 N.m.
11. Check for gas leakage.

## 1.3 Re-Installation

### 1.3.1 Indoor Unit


#### Collecting the refrigerant into the outdoor unit



#### Procedure:

1. Confirm that the 2- and 3-way valves are opened.
2. Remove the valve stem caps and ensure that the valve stems are opened (use a hexagonal wrench to open the valve stems).
3. Connect the charge hose with the push pin of Handle Lo to the 3-way valve's gas service port.
4. Open the Handle Lo valve of the manifold valve to purge air from the charge hose for 5 seconds and then close it quickly.
5. Close the 2-way valve.
6. Operate the air conditioner in cooling mode. Cease operations when the gauge reaches 0.1 MPa (14.5 Psi).
7. Close the 3-way valve so that the gauge rests between 0.3 MPa (43.5 Psi) and 0.5 MPa (72.5 Psi).
8. Disconnect the charge set, and tighten the 2- and 3-way valve's stem nuts (use a torque wrench to tighten the 3-way valve's service port cap to a torque of 18 N.m).
9. Check for gas leakage.

## Air purging with vacuum pump




### Procedure:

1. Tighten the flare nuts of the indoor and outdoor units, and confirm that both the 2- and 3-way valves are closed.
2. Connect the charge hose with the push pin of Handle Lo to the gas service port of the 3-way valve.
3. Connect the charge hose of Handle Hi connection to the vacuum pump.
4. Fully open the Handle Lo manifold valve.
5. Using the vacuum pump, evacuate the system for 30 minutes.
  - a. Check whether the compound meter indicates -0.1 MPa (14.5 Psi).
    - If the meter does not indicate -0.1 MPa (14.5 Psi) after 30 minutes, continue evacuating for an additional 20 minutes.
    - If the pressure does not achieve -0.1 MPa (14.5 Psi) after 50 minutes, check for leakage.
    - If the pressure successfully reaches -0.1 MPa (14.5 Psi), fully close the Handle Lo valve and cease vacuum pump operations.
  - b. Wait for 5 minutes then check whether the gauge needle moves after turning off the vacuum pump.
6. Loosen the flare nut of the 3-way valve for 6 or 7 seconds and then tighten the flare nut again.
  - c. Confirm the pressure display in the pressure indicator is slightly higher than the atmospheric pressure.
  - d. Remove the charge hose from the 3-way valve.
7. Fully open the 2- and 3-way valves and tighten the cap of the 3-way valve.

### 1.3.2 Outdoor Unit


#### Evacuation for the whole system



#### Procedure:

1. Confirm that the 2- and 3-way valves are opened.
2. Connect the vacuum pump to the 3-way valves service port.
3. Evacuate the system for approximately one hour.  
Confirm that the compound meter indicates -0.1 MPa (14.5Psi).
4. Close the valve (Low side) on the charge set and turn off the vacuum pump.
5. Wait a period of five minutes then check whether the gauge needle moves after turning off the vacuum pump.
6. Disconnect the charge hose from the vacuum pump.

## Refrigerant charging



### Procedure:

1. Connect the charge hose to the 3-way service port and then open the 2- and the 3-way valves.
2. Connect the charge hose to the valve at the bottom of the cylinder.
3. If the refrigerant is R410A, invert the cylinder to ensure a complete liquid charge.
4. Open the valve at the bottom of the cylinder and close the check valve on the charge set to purge the air.
5. Place the charging cylinder onto an electronic scale and record the starting weight.
6. Operate the air conditioner in cooling mode.
7. Open the valves (Low side) on the charge set and charge the system with liquid refrigerant.
8. When the electronic scale displays the correct weight (refer to the gauge and the pressure of the low side to confirm), disconnect the charge hose from the 3-way valves service port immediately and turn off the air conditioner before disconnecting the hose.
9. Mount the valve stem caps and the service port.
10. Use a torque wrench to tighten the service port cap to a torque of 18 N.m.
11. Check for gas leakage.



**Note: 1. Mechanical connectors used indoors shall comply with local regulations.**

**2. When mechanical connectors are reused indoors, sealing parts shall be renewed. When flared joints are reused indoors, the flare part shall be re-fabricated.**

## 2. Disassembly

### 2.1 Indoor unit

#### 1. Front Panel


| Procedure  | Illustration   |
|--|--|
| <p>1) Hold the front panel by the tabs on the both sides and lift it (see CJ_AF_INV_001).</p>      |  <p style="text-align: center;"><b>CJ_AF_INV_001</b></p>   |
| <p>2) Push up the bottom of an air filter, and then pull it out downwards (see CJ_AF_INV_002).</p> |  <p style="text-align: center;"><b>CJ_AF_INV_002</b></p> |

**Note:** This section is for reference only. Actual unit appearance may vary.


**Procedure**

**Illustration**

- 3) Open the horizontal louver and push the hook towards left to open it (see CJ\_AF\_INV\_003).




- 4) Bend the horizontal louver lightly by both hands to loosen the hooks, then remove the horizontal louver (see CJ\_AF\_INV\_004).




Note: This section is for reference only. Actual unit appearance may vary.

5) Remove 1 screw and then remove the electrical cover(see CJ\_AF\_INV\_005-1 and CJ\_AF\_INV\_005-2).



CJ\_AF\_INV\_005-1




CJ\_AF\_INV\_005-2

6) Disconnect the connector for display board(see CJ\_AF\_INV\_005-3) .



CJ\_AF\_INV\_005-3

7) Remove the display board(see CJ\_AF\_INV\_005-4).



CJ\_AF\_INV\_005-4

CJ\_AF\_INV\_005


**Note:** This section is for reference only. Actual unit appearance may vary.



**Procedure**


**Illustration**

- 8) Open the screw caps(2) and the remove the screws(see CJ\_AF\_INV\_006).
- 9) Release the 4 hooks.



**CJ\_AF\_INV\_006**

- 10)Release the seven hooks in the back (see CJ\_AF\_INV\_007).




**CJ\_AF\_INV\_007**

**Note:** This section is for reference only. Actual unit appearance may vary.

## Procedure

11) Pull out the panel frame while pushing the hook through a clearance between the panel frame and the heat exchanger (see CJ\_AF\_INV\_008).



## Illustration



**Note:** This section is for reference only. Actual unit appearance may vary.


## 2. Electrical parts

**Note:** Remove the front panel (refer to 1. Front panel) before disassembling electrical parts.


| Procedure   | Illustration   |
|---|--|
| <p>1) Remove the fixing screw and then remove the cover of electronic box and the terminal cover (see CJ_AF_INV_009).</p>   |  <p data-bbox="909 1108 1133 1153">CJ_AF_INV_009</p>  |
| <p>2) Pull out the room temperature sensor (T1) and the coil temperature sensor (T2) (see CJ_AF_INV_010).</p> <p>3) Remove the two screws used for the ground connection (see CJ_AF_INV_010).</p> |  <p data-bbox="909 1870 1133 1915">CJ_AF_INV_010</p> |

**Note:** This section is for reference only. Actual unit appearance may vary.

- 4) Remove the fixing screw (see CJ\_AF\_INV\_011-1).
- 5) Pull out the Electrical control box along the direction indicated in right image. to remove it (CJ\_AF\_INV\_011-2).



- 6) Disconnect the wires. Then remove the electronic main board (CJ\_AF\_INV\_012).




**Note:** This section is for reference only. Actual unit appearance may vary.

## Procedure

- 7) Remove the fixing screw, then remove the capacitor of fan motor (see CJ\_AF\_INV\_013).




## Illustration



Note: This section is for reference only. Actual unit appearance may vary.


### 3. Evaporator

**Note:** Remove the front panel and electrical parts (refer to 1. Front panel and 2. Electrical parts) before disassembling evaporator.

| Procedure   | Illustration  |
|---|---|
| 1) Disassemble the pipe holder located at the rear of the unit (see CJ_AF_INV_014).                     |  <p>Pipe Holder</p> <p><b>CJ_AF_INV_014</b></p> |
| 2) Remove the screws on the evaporator located at the fixed plate (see CJ_AF_INV_015).                  |  <p>Screws</p> <p><b>CJ_AF_INV_015</b></p>     |
| 3) Remove the two screws on the evaporator located at the base of the bearing side (see CJ_AF_INV_016). |  <p>Screws</p> <p><b>CJ_AF_INV_016</b></p>    |

**Note:** This section is for reference only. Actual unit appearance may vary.






| Procedure                                       | Illustration   |
|---|--|
| 4) Pull out the evaporator (see CJ_AF_INV_017). |  <p data-bbox="938 837 1155 873">CJ_AF_INV_017</p> |

Note: This section is for reference only. Actual unit appearance may vary.

#### 4. Fan motor and fan

**Note:** Remove the front panel, electrical parts and evaporator (refer to 1. Front panel, 2. Electrical parts, and 3. Evaporator). before disassembling fan motor and fan.


| Procedure  | Illustration  |
|--|---|
| 1) Remove the two screws and remove the fixing board of the fan motor (see CJ_AF_INV_018).                   |  <p style="text-align: center;">CJ_AF_INV_018</p>   |
| 2) Remove the Bearing sleeve(see CJ_AF_INV_019).   |  <p style="text-align: center;">CJ_AF_INV_019</p>  |
| 3) Remove the fixing screw (see CJ_AF_INV_020).<br>4) Pull out the fan motor and fan assembly from the side. |  <p style="text-align: center;">CJ_AF_INV_020</p> |

**Note:** This section is for reference only. Actual unit appearance may vary.



## 5. Step motor

**Note:** Remove the front panel and electrical parts (refer to 1. Front panel, 2. Electrical parts) before disassembling step motor.



| Procedure   | Illustration   |
|---|--|
| 1) Remove the two screws, then remove the stepping motor (see CJ_AF_INV_021). |  <p data-bbox="925 884 1069 918">Stepping Motor</p> <p data-bbox="925 974 1149 1019">CJ_AF_INV_021</p> |

**Note:** This section is for reference only. Actual unit appearance may vary.

## 2.2 Outdoor unit


### 1. Panel Plate

ACP-09CH25AEMI/O; ACP-12CH35AEMI/O:

| Procedure  | Illustration  |
|--|---|
| <p>1) Turn off the air conditioner and the power breaker.</p> <p>2) Remove the screws of the big handle and then remove the big handle (3 screws) (see CJ_BA30_INV_001).</p> |  <p>Big Handle</p> <p>For US models (3 screws)</p> <p>CJ_BA30_INV_001</p> |
| <p>3) Remove the screws of the top cover and then remove the top cover (3 screws). One of the screws is located underneath the big handle (see CJ_BA30_INV_002).</p>         |  <p>Top Cover</p> <p>CJ_BA30_INV_002</p>                                |


Note: This section is for reference only. Actual unit appearance may vary.

- 4) Remove the screws of the front panel and then remove the front panel (7 screws) (see CJ\_BA30\_INV\_003).



CJ\_BA30\_INV\_003

- 5) Remove the screws of the rear net and then remove the rear net (2 screws) (see CJ\_BA30\_INV\_004).




CJ\_BA30\_INV\_004

Note: This section is for reference only. Actual unit appearance may vary.

## Procedure

- 6) Remove the screws of the right panel and then remove the right panel (5 screws) (see CJ\_BA30\_INV\_005).

## Illustration



CJ\_BA30\_INV\_005



Note: This section is for reference only. Actual unit appearance may vary.

ACP-18CH50AEMI/O, ACP-18CH50AEMI/O


Procedure

Illustration

- 1) Turn off the air conditioner and the power breaker.
- 2) Remove the screws of the big handle and then remove the big handle (3 screws) (see CJ\_B30\_INV\_001).




- 3) Remove the screws of the top cover and then remove the top cover (3 screws). One of the screws is located underneath the big handle (see CJ\_B30\_INV\_002).




Note: This section is for reference only. Actual unit appearance may vary.

- 4) Remove the screws of the front panel and then remove the front panel (8 screws) (see CJ\_B30\_INV\_003).



CJ\_B30\_INV\_003

- 5) Remove the screws of water collecting cover and then remove the water collecting cover (1 screw) (see CJ\_B30\_INV\_004).




CJ\_B30\_INV\_004

Note: This section is for reference only. Actual unit appearance may vary.

## Procedure

- 6) Remove the screws of the right panel and then remove the right panel (5 screws) (see CJ\_B30\_INV\_005).

## Illustration





CJ\_B30\_INV\_005

Note: This section is for reference only. Actual unit appearance may vary.



## ACP-24CH70AEM/O:

| Procedure  | Illustration  |
|--|---|
| <p>1) Turn off the air conditioner and the power breaker.</p> <p>2) Remove the screws of the big handle and then remove the big handle (3 screws) (see CJ_CA30_INV_001).</p> |  <p>Big Handle</p> <p>For US models (3 screws)</p> <p><b>CJ_CA30_INV_001</b></p> |
| <p>3) Remove the screws of the top cover and then remove the top cover (3 screws). One of the screws is located underneath the big handle (see CJ_CA30_INV_002).</p>         |  <p>Top Cover</p> <p><b>CJ_CA30_INV_002</b></p>                                 |


Note: This section is for reference only. Actual unit appearance may vary.



**Procedure**


**Illustration**

- 4) Remove the screws of the front panel and then remove the front panel (7 screws) (see CJ\_CA30\_INV\_003).



**CJ\_CA30\_INV\_003**

- 5) Remove the screws of water collecting cover and then remove the water collecting cover (1 screw) (see CJ\_CA30\_INV\_004).




**CJ\_CA30\_INV\_004**

**Note:** This section is for reference only. Actual unit appearance may vary.

## Procedure

- 6) Remove the screws of the right panel and then remove the right panel (6 screws) (see CJ\_CA30\_INV\_005).

## Illustration






CJ\_CA30\_INV\_005

Note: This section is for reference only. Actual unit appearance may vary.

## 2. Fan disassembly

Note: Remove the panel plate and (refer to 1. Panel plate) before disassembling fan.

ACP-09CH25AEMI/O; ACP-12CH35AEMI/O; ACP-18CH50AEMI/O; MOB32-18HFN1-QRD0GW(S1)


| Procedure  | Illustration  |
|--|---|
| <p>1) Remove the nut securing the fan with a spanner (see CJ_ODU_INV_001).</p> <p>2) Remove the fan.</p> |  <p>D;cut</p> <p><b>CJ_ODU_INV_001</b></p>  |
| <p>3) Remove the screws of the top cover. (2 screws) (see CJ_ODU_INV_002).</p>                           |  <p><b>CJ_ODU_INV_002</b></p>              |
| <p>4) Unfix the hooks and then open the electronic control box cover (4 hooks) (see CJ_ODU_INV_003).</p> |  <p>Hook</p> <p><b>CJ_ODU_INV_003</b></p> |

Note: This section is for reference only. Actual unit appearance may vary.


## Procedure

- 5) Disconnect the connector for fan motor from the electronic control board (see CJ\_ODU\_INV\_004).

## Illustration



- 6) Remove the fixing screws of the fan motor (4 screws) (see CJ\_ODU\_INV\_005).
- 7) Remove the fan motor.




**Note:** This section is for reference only. Actual unit appearance may vary.

ACP-24CH70AEM/O:

Procedure


Illustration

- 1) Remove the nut securing the fan with a spanner (see CJ\_ODU\_INV\_006).
- 2) Remove the fan.



CJ\_ODU\_INV\_006


- 3) Unfix the hooks and then open the electronic control box cover (4 hooks) (see CJ\_ODU\_INV\_007).



CJ\_ODU\_INV\_007


Note: This section is for reference only. Actual unit appearance may vary.

- 4) Disconnect the connector for fan motor from the electronic control board (see CJ\_ODU\_INV\_008).



CJ\_ODU\_INV\_008

- 5) Remove the fixing screws of the fan motor (4 screws) (see CJ\_ODU\_INV\_009).
- 6) Remove the fan motor.



CJ\_ODU\_INV\_009


**Note:** This section is for reference only. Actual unit appearance may vary.




### 3. Electrical parts

**Note:** Remove the panel plate and fan assembly (refer to 1. Panel plate and 2. Fan assembly) before disassembling electrical parts.

**ACP-09CH25AEMI/O; ACP-12CH35AEMI/O; ACP-18CH50AEMI/O; MOB32-18HFN1-QRD0GW(S1) :**

| Procedure  | Illustration  |
|--|---|
| <ol style="list-style-type: none"><li>1) Remove the connector for the compressor (see CJ_ODU_INV_010).</li><li>2) Pull out the two blue wires connected with the four way valve (CJ_ODU_INV_010).</li><li>3) Pull out connectors of the condenser coil temp. sensor(T3), outdoor ambient temp. sensor(T4) and discharge temp. sensor(TP) (CJ_ODU_INV_010).</li><li>4) Disconnect the electronic expansion valve wire (CJ_ODU_INV_010).</li><li>5) Then remove the electronic control box (see CJ_ODU_INV_010).</li></ol> |  |

## ACP-24CH70AEMI/O:


| Procedure  | Illustration  |
|--|---|
| <ol style="list-style-type: none"><li>1) Remove the connector for the compressor (see CJ_ODU_INV_011).</li><li>2) Pull out the two blue wires connected with the four way valve (see CJ_ODU_INV_011).</li><li>3) Pull out connectors of the condenser coil temp. sensor(T3), outdoor ambient temp. sensor(T4) and discharge temp. sensor(T5) (see CJ_ODU_INV_011).</li><li>4) Disconnect the electronic expansion valve wire (see Fig CJ_ODU_INV_011).</li><li>5) Remove the connector for electric heaters (see Fig CJ_ODU_INV_011).</li><li>6) Remove the connector for the DR and reactor (see Fig CJ_ODU_INV_011).</li><li>7) Then remove the electronic control box (see Fig CJ_ODU_INV_011).</li></ol> |  <p>CJ_ODU_INV_011</p> |

Note: This section is for reference only. Actual unit appearance may vary.



#### 4. Reactor(for 18k and 24k)


**Note:** Remove the panel plate, electrical parts, and fan assembly (refer to 1. Panel plate, 2. Electrical parts, and 3. Fan assembly) before disassembling sound blanket.

| Procedure   | Illustration   |
|---|--|
| 1) Remove the 2 screws of the reactor and then remove the reactor (see CJ_ODU_INV_012). |  <p>CJ_ODU_INV_012</p> |

#### 5. Sound blanket

**WARNING:** Recover refrigerant from the refrigerant circuit before remove the compressor.

**Note:** Remove the panel plate, electrical parts, and fan assembly (refer to 1. Panel plate, 2. Electrical parts, and 3. Fan assembly) before disassembling sound blanket.


| Procedure  | Illustration  |
|--|---|
| 1) Remove the sound blanket (side and top) (see CJ_ODU_INV_013). |  <p>Sound Blanket(top)</p> <p>Sound Blanket(side)</p> <p>CJ_ODU_INV_013</p> |

**Note:** This section is for reference only. Actual unit appearance may vary.

## 6. Four-way valve

**⚠ WARNING:** Recover refrigerant from the refrigerant circuit before remove the four-way valve.

**Note:** Remove the panel plate, electrical parts, and fan assembly (refer to 1. Panel plate, 2. Electrical parts, and 3. Fan assembly) before disassembling four-way valve.



| Procedure  | Illustration   |
|--|--|
| <ol style="list-style-type: none"><li>1) Heat up the brazed parts and then detach the the four-way valve and the pipe (see CJ_ODU_INV_014).</li><li>2) Remove the four-way valve assembly with pliers.</li></ol> |  <p data-bbox="925 1601 1165 1635">CJ_ODU_INV_014</p> |

**Note:** This section is for reference only. Actual unit appearance may vary.

## 7. Compressor


**⚠ WARNING:** Recover refrigerant from the refrigerant circuit before remove the compressor.

**Note:** Remove the panel plate, electrical parts, and fan assembly (refer to 1. Panel plate, 2. Electrical parts, and 3. Fan assembly) before disassembling compressor.

| Procedure   | Illustration   |
|---|--|
| <p>1) Remove the flange nut of terminal cover and remove the terminal cover (see CJ_ODU_INV_015).</p> |  <p>The diagram shows a top-down view of the compressor assembly. A dashed line points to a flange nut on the terminal cover. The label 'Terminal Cover' is positioned to the left of the nut. The compressor is mounted on a base with various hoses and electrical connections.</p> <p>CJ_ODU_INV_015</p> |
| <p>2) Disconnect the connectors (see CJ_ODU_INV_016).</p>   |  <p>The diagram shows a close-up of a hand pulling a connector away from the compressor. An upward-pointing arrow indicates the direction of removal. The connector is attached to a bundle of wires.</p> <p>CJ_ODU_INV_016</p>  |


Note: This section is for reference only. Actual unit appearance may vary.

- 3) Remove the hex nuts and washers securing the compressor, located on the bottom plate (see CJ\_ODU\_INV\_017).



CJ\_ODU\_INV\_017

- 4) Heat up the brazed parts and then remove the the discharge pipe and the suction pipe (see CJ\_ODU\_INV\_018).
- 5) Lift the compressor from the base pan assembly with pliers.



CJ\_ODU\_INV\_018

Note: This section is for reference only. Actual unit appearance may vary.

# Troubleshooting

## Contents

|  |           |
|--|-----------|
| <b>1. Safety Caution .....</b>   | <b>58</b> |
| <b>2. General Troubleshooting .....</b>  | <b>59</b> |
| <b>3. Error Diagnosis and Troubleshooting Without Error Code.....</b>                                | <b>60</b> |
| 3.1 Remote maintenance.....  | 60        |
| 3.2 Field maintenance .....  | 61        |
| <b>4. Quick Maintenance by Error Code.....</b>   | <b>62</b> |
| <b>5. Troubleshooting by Error Code.....</b>   | <b>67</b> |
| 5.1 Common Check Procedures.....   | 67        |
| 5.2 E0/F4 (EEPROM parameter error) .....   | 69        |
| 5.3 E1 (Indoor and outdoor unit communication error) .....   | 70        |
| 5.4 E3/F5 (Fan speed is operating outside of the normal range diagnosis and solution) .....          | 72        |
| 5.5 E4/E5/F1/F2/F3 (Open circuit or short circuit of temperature sensor diagnosis and solution)..... | 74        |
| 5.6 E7 (Indoor PCB /Display board communication error) .....   | 75        |
| 5.7 EC (Refrigerant Leakage Detection diagnosis and solution) .....                                  | 76        |
| 5.8 F0(Overload current protection diagnosis and solution) .....                                     | 77        |
| 5.9 P0(IPM malfunction or IGBT over-strong current protection diagnosis and solution) .....          | 78        |

---




# Contents

|      |   |    |
|------|---|----|
| 5.10 | P1(Over voltage or too low voltage protection diagnosis and solution) ..... | 79 |
| 5.11 | P2(High temperature protection of IPM module diagnosis and solution) .....  | 80 |
| 5.12 | P4(Inverter compressor drive error diagnosis and solution) .....            | 81 |


## 1. Safety Caution

### WARNING

Electricity remains in capacitors even when the power supply is off.  
Ensure the capacitors are fully discharged before troubleshooting.



For other models, connect discharge resistance (approx.  $100\Omega$  40W) or a soldering iron plug between the positive and negative terminals of the electrolytic capacitor. The terminals are located on the bottom surface of the outdoor PCB.



Note: This picture is for reference only. Actual appearances may vary.

## 2. General Troubleshooting

### 2.1 Error Display (Indoor Unit)

When the indoor unit encounters a recognized error, the indicator light will flash in a corresponding series, the timer display may turn on or begin flashing, and an error code will be displayed. These error codes are described in the following table:

| Indicator flashes | Timer Display | Display | Error Information   | Solution |
|-------------------|---------------|---------|---|----------|
| 1                 | OFF           | E0      | Indoor unit EEPROM parameter error  | Page 69  |
| 2                 | OFF           | E1      | Indoor / outdoor units communication error                                      | Page 70  |
| 4                 | OFF           | E3      | The indoor fan speed is operating outside of the normal range                   | Page 72  |
| 5                 | OFF           | E4      | Indoor room temperature sensor T1 is in open circuit or has short circuited     | Page 74  |
| 6                 | OFF           | E5      | Evaporator coil temperature sensor T2 is in open circuit or has short circuited | Page 74  |
| 9                 | OFF           | E7      | Indoor PCB /Display board communication error                                   | Page 75  |
| 7                 | OFF           | EC      | Refrigerant leak detected   | Page 76  |
| 1                 | ON            | F0      | Overload current protection   | Page 77  |
| 2                 | ON            | F1      | Outdoor ambient temperature sensor T4 open circuit or short circuit             | Page 74  |
| 3                 | ON            | F2      | Condenser coil temperature sensor T3 is in open circuit or has short circuited  | Page 74  |
| 4                 | ON            | F3      | Compressor discharge temperature sensor TP open circuit or short circuit        | Page 74  |
| 5                 | ON            | F4      | Outdoor unit EEPROM parameter error   | Page 69  |
| 6                 | ON            | F5      | The outdoor fan speed is operating outside of the normal range                  | Page 72  |
| 1                 | FLASH         | p0      | IPM malfunction or IGBT over-strong current protection                          | Page 78  |
| 2                 | FLASH         | p1      | Over voltage or over low voltage protection                                     | Page 79  |
| 3                 | FLASH         | p2      | High temperature protection of IPM module                                       | Page 80  |
| 5                 | FLASH         | p4      | Inverter compressor drive error   | Page 81  |

#### For other errors:

The display board may show a garbled code or a code undefined by the service manual. Ensure that this code is not a temperature reading.

#### Troubleshooting:

Test the unit using the remote control. If the unit does not respond to the remote, the indoor PCB requires replacement. If the unit responds, the display board requires replacement.



### 3. Error Diagnosis and Troubleshooting Without Error Code

#### WARNING

Be sure to turn off unit before any maintenance to prevent damage or injury.

#### 3.1 Remote maintenance

**SUGGESTION:** When troubles occur, please check the following points with customers before field maintenance.

| Problem |  | Solution   |
|---------|--|------------|
| 1       | Unit will not start                                      | Page 63-64 |
| 2       | The power switch is on but fans will not start           | Page 63-64 |
| 3       | The temperature on the playboard cannot be setted        | Page 63-64 |
| 4       | Unit is on but the wind is not cold(hot)                 | Page 63-64 |
| 5       | Unit runs, but shortly stops                             | Page 63-64 |
| 6       | The unit startup and stop frequently                     | Page 63-64 |
| 7       | Unit runs continuously but insufficient cooling(heating) | Page 63-64 |
| 8       | Cool can not change to heat                              | Page 63-64 |
| 9       | Unit is noisy  | Page 63-64 |

## 3.2 Field maintenance

| Problem |   | Solution   |
|---------|---|------------|
| 1       | Unit will not start                                   | Page 65-66 |
| 2       | Compressor will not start but fans run                | Page 65-66 |
| 3       | Compressor and condenser (outdoor) fan will not start | Page 65-66 |
| 4       | Evaporator (indoor) fan will not start                | Page 65-66 |
| 5       | Condenser (Outdoor) fan will not start                | Page 65-66 |
| 6       | Unit runs, but shortly stops                          | Page 65-66 |
| 7       | Compressor short-cycles due to overload               | Page 65-66 |
| 8       | High discharge pressure                               | Page 65-66 |
| 9       | Low discharge pressure                                | Page 65-66 |
| 10      | High suction pressure                                 | Page 65-66 |
| 11      | Low suction pressure                                  | Page 65-66 |
| 12      | Unit runs continuously but insufficient cooling       | Page 65-66 |
| 13      | Too cool  | Page 65-66 |
| 14      | Compressor is noisy                                   | Page 65-66 |
| 15      | Horizontal louver can not revolve                     | Page 65-66 |

## 4. Quick Maintenance by Error Code

If you do not have the time to test whether specific parts are faulty, you can directly change the required parts according to the error code.

You can find the parts to replace by error code in the following table.

| Part requiring replacement | Error Code |    |    |    |    |    |    |    |    |
|----------------------------|------------|----|----|----|----|----|----|----|----|
|                            | E0         | E1 | E3 | E4 | E5 | E7 | EC | F0 | F1 |
| Indoor PCB                 |            | ✓  |    | ✓  |    | ✓  |    | x  | x  |
| Outdoor PCB                | x          | ✓  | x  | x  | x  | x  | x  | ✓  |    |
| Reactor                    | x          | ✓  | x  | x  | x  | x  | x  | x  | x  |
| Indoor fan motor           | x          | x  |    | x  | x  | x  | x  | x  | x  |
| Outdoor fan motor          | x          | x  | X  | x  | x  | x  | x  | x  | x  |
| Temperature sensor         | x          | x  | x  |    |    | x  |    | x  |    |
| T2 Sensor                  | x          | x  | x  | ✓  | x  | x  |    | x  | x  |
| Additional refrigerant     | x          | x  | x  | x  | x  | x  | x  | x  | x  |
| Compressor                 | x          | x  | x  | x  | x  | x  | x  |    | x  |
| IPM board                  | x          | x  | x  | x  | x  | x  | x  | ✓  | x  |
| Outdoor unit               | x          | x  | x  | x  | x  | x  | x  |    | x  |
| Display board              | x          | x  | x  | x  | x  |    | x  | ✓  | x  |

| Part requiring replacement | Error Code |    |    |    |    |    |    |    |
|----------------------------|------------|----|----|----|----|----|----|----|
|                            | F2         | F3 | F4 | F5 | P0 | P1 | P2 | P4 |
| Indoor PCB                 | x          | x  | x  | x  | x  | x  | x  | x  |
| Outdoor PCB                |            |    |    |    |    |    |    |    |
| Reactor                    | x          | ✓  | x  | ✓  | x  | ✓  | x  | ✓  |
| Indoor fan motor           | x          | x  | x  | x  | x  | ✓  | x  | x  |
| Outdoor fan motor          | x          | x  | x  |    | x  | x  | x  | x  |
| Temperature sensor         |            |    | x  | ✓  | x  | X  | x  | x  |
| T2 Sensor                  | x          | ✓  | x  | x  | x  | x  | x  | x  |
| Additional refrigerant     | x          | x  | x  | x  | x  | x  | x  | x  |
| Compressor                 | x          | x  | x  | x  |    | x  | x  |    |
| IPM board                  | x          | x  | x  | x  |    | ✓  | x  | ✓  |
| Outdoor unit               | x          | x  | x  | x  | x  | x  | x  | x  |

| 1.Remote Maintenance   | Electrical Circuit |                        |                               |                        |                                    | Refrigerant Circuit                       |                            |                  |                      |  |  |                     |  |                                    |
|--|--------------------|------------------------|-------------------------------|------------------------|------------------------------------|---|----------------------------|------------------|----------------------|--|--|---------------------|--|------------------------------------|
| <b>Possible causes of trouble</b>                            | Power failure      | The main power tripped | Loose connections             | Faulty transformer     | The voltage is too high or too low | The remote control is powered off         | Broken remote control      | Dirty air filter | Dirty condenser fins | The setting temperature is higher/lower than the room's(cooling/heating) | The ambient temperature is too high/low when the mode is cooling/heating | Fan mode            | SILENCE function is activated(optional function) | Frosting and defrosting frequently |
| Unit will not start  | ☆                  | ☆                      | ☆                             | ☆                      |                                    |   |                            |                  |                      |  |  |                     |  |                                    |
| Operation is erratic, unpredictable, or unit is unresponsive |                    |                        |                               |                        |                                    |   |                            |                  |                      |  |  |                     |  |                                    |
| The temperature on the playboard cannot be setted            |                    |                        |                               |                        |                                    | ☆   | ☆                          |                  |                      |  |  |                     |  |                                    |
| Unit is on but the wind is not cold(hot)                     |                    |                        |                               |                        |                                    |   |                            |                  |                      | ☆  | ☆  | ☆                   |  |                                    |
| Unit runs, but shortly stops                                 |                    |                        |                               |                        | ☆                                  |   |                            |                  |                      | ☆  | ☆  |                     |  |                                    |
| The unit startup and stop frequently                         |                    |                        |                               |                        | ☆                                  |   |                            |                  |                      |  | ☆  |                     |  | ☆                                  |
| Unit runs continuously but insufficient cooling(heating)     |                    |                        |                               |                        |                                    |   |                            | ☆                | ☆                    | ☆  | ☆  |                     | ☆  |                                    |
| Cool can not change to heat                                  |                    |                        |                               |                        |                                    |   |                            |                  |                      |  |  |                     |  |                                    |
| Unit is noisy  |                    |                        |                               |                        |                                    |   |                            |                  |                      |  |  |                     |  |                                    |
| The unit emits a bad odor                                    |                    |                        |                               |                        |                                    |   |                            | ☆                |                      |  |  |                     |  |                                    |
| <b>Test method / remedy</b>                                  | Test voltage       | Close the power switch | Inspect connections - tighten | Change the transformer | Test voltage                       | Replace the battery of the remote control | Replace the remote control | Clean or replace | Clean                | Adjust the setting temperature   | Turn the AC later  | Adjust to cool mode | Turn off SILENCE function.                       | Turn the AC later                  |

|  |  |   |   |   |  |  |  |   |  |   |
|--|--|---|---|---|--|--|--|---|--|---|
| Check heat load  |  |   | ☆ |   |  |  |  |   |  | Heavy load condition                                    |
| Tighten bolts or screws  |  | ☆ |   |   |  |  |  |   |  | Loosen hold down bolts and / or screws                  |
| Close all the windows and doors  |  |   | ☆ |   |  |  |  |   |  | Bad airproof  |
| Remove the obstacles   |  |   | ☆ | ☆ |  |  |  |   |  | The air inlet or outlet of either unit is blocked       |
| Reconnect the power or press <b>ON/OFF</b> button on remote control to restart |  |   |   |   |  |  |  | ☆ |  | Interference from cell phone towers and remote boosters |
| Remove them  |  | ☆ |   |   |  |  |  |   |  | Shipping plates remain attached                         |

Others

| 2.Field Maintenance                                   | Electrical Circuit |                          |                               |                           |                                  |   |  |                                   |                             |  |                                    |              |                            |                                     |                                     |
|---|--------------------|--------------------------|-------------------------------|---------------------------|----------------------------------|---|--|-----------------------------------|-----------------------------|--|------------------------------------|--------------|----------------------------|-------------------------------------|-------------------------------------|
| Possible causes of trouble                            | Power failure      | Blown fuse or varistor   | Loose connections             | Shorted or broken wires   | Safety device opens              | Faulty thermostat / room temperature sensor     | Wrong setting place of temperature sensor      | Faulty transformer                | Shorted or open capacitor   | Faulty magnetic contactor for compressor | Faulty magnetic contactor for fan  | Low voltage  | Faulty stepping motor      | Shorted or grounded compressor      | Shorted or grounded fan motor       |
| Unit will not start                                   | ☆                  | ☆                        | ☆                             | ☆                         | ☆                                |   |  | ☆                                 |                             |  |                                    |              |                            |                                     |                                     |
| Compressor will not start but fans run                |                    |                          |                               | ☆                         |                                  | ☆   |  |                                   | ☆                           | ☆  |                                    |              |                            | ☆                                   |                                     |
| Compressor and condenser (outdoor) fan will not start |                    |                          |                               | ☆                         |                                  | ☆   |  |                                   |                             | ☆  |                                    |              |                            |                                     |                                     |
| Evaporator (indoor) fan will not start                |                    |                          |                               | ☆                         |                                  |   |  |                                   | ☆                           |  | ☆                                  |              |                            |                                     | ☆                                   |
| Condenser (Outdoor) fan will not start                |                    |                          |                               | ☆                         |                                  | ☆   |  |                                   | ☆                           | ☆  |                                    |              |                            |                                     | ☆                                   |
| Unit runs, but shortly stops                          |                    |                          |                               |                           |                                  |   |  |                                   |                             | ☆  |                                    | ☆            |                            |                                     |                                     |
| Compressor short-cycles due to overload               |                    |                          |                               |                           |                                  |   |  |                                   |                             | ☆  |                                    | ☆            |                            |                                     |                                     |
| High discharge pressure                               |                    |                          |                               |                           |                                  |   |  |                                   |                             |  |                                    |              |                            |                                     |                                     |
| Low discharge pressure                                |                    |                          |                               |                           |                                  |   |  |                                   |                             |  |                                    |              |                            |                                     |                                     |
| High suction pressure                                 |                    |                          |                               |                           |                                  |   |  |                                   |                             |  |                                    |              |                            |                                     |                                     |
| Low suction pressure                                  |                    |                          |                               |                           |                                  |   |  |                                   |                             |  |                                    |              |                            |                                     |                                     |
| Unit runs continuously but insufficient cooling       |                    |                          |                               |                           |                                  |   |  |                                   |                             |  |                                    |              |                            |                                     |                                     |
| Too cool  |                    |                          |                               |                           | ☆                                | ☆   |  |                                   |                             |  |                                    |              |                            |                                     |                                     |
| Compressor is noisy                                   |                    |                          |                               |                           |                                  |   |  |                                   |                             |  |                                    |              |                            |                                     |                                     |
| Horizontal louver can not revolve                     |                    |                          | ☆                             | ☆                         |                                  |   |  |                                   |                             |  |                                    | ☆            |                            |                                     |                                     |
| Test method / remedy                                  | Test voltage       | Inspect fuse type & size | Inspect connections - tighten | Test circuits with tester | Test continuity of safety device | Test continuity of thermostat / sensor & wiring | Place the temperature sensor at the central of | Check control circuit with tester | Check capacitor with tester | Test continuity of coil & contacts       | Test continuity of coil & contacts | Test voltage | Replace the stepping motor | Check resistance with megger tester | Check resistance with megger tester |



## 5. Troubleshooting by Error Code

### 5.1 Common Check Procedures

#### 5.1.1 Temperature Sensor Check

Disconnect the temperature sensor from PCB, measure the resistance value with a tester.

Temperature Sensors.

Room temp.(T1) sensor, Indoor coil

temp.(T2) sensor, Outdoor coil

temp.(T3) sensor, Outdoor ambient


temp.(T4) sensor,

Compressor discharge temp.(Tp) sensor.

Measure the resistance value of each winding by using the multi-meter.

#### 5.1.2 Compressor checking

Measure the resistance value of each winding by using the tester.



| Position     | Resistance Value |                  |                  |                  |
|--------------|------------------|------------------|------------------|------------------|
|              | ASK89D53UEZ      | ASM135D23UFZ     | ASN140D21UFZ     | ATF235D22UMT     |
| Blue - Red   | 2.35Ω(20°C/68°F) | 1.75Ω(20°C/68°F) | 1.28Ω(20°C/68°F) | 0.75Ω(20°C/68°F) |
| Blue - Black |                  |                  |                  |                  |
| Red - Blue   |                  |                  |                  |                  |





### 5.1.3 IPM Continuity Check

Turn off the power, let the large capacity electrolytic capacitors discharge completely, and dismount the IPM. Use a digital tester to measure the resistance between P and UVWN; UVW and N.

| Digital tester |          | Normal resistance value           | Digital tester |          | Normal resistance value           |
|----------------|----------|-----------------------------------|----------------|----------|-----------------------------------|
| (+)Red         | (-)Black |                                   | (+)Red         | (-)Black |                                   |
| P              | N        | $\infty$<br>(Several M $\Omega$ ) | U              | N        | $\infty$<br>(Several M $\Omega$ ) |
|                | U        |                                   | V              |          |                                   |
|                | V        |                                   | W              |          |                                   |
|                | W        |                                   | (+)Red         |          |                                   |


## 5.2 E0/F4 (EEPROM parameter error)

**Description:** Indoor or outdoor PCB main chip does not receive feedback from EEPROM chip.

### Recommended parts to prepare:


- Indoor PCB
- Outdoor PCB

### Troubleshooting and repair:



### Remarks:

The location of the EEPROM chip on the indoor and outdoor PCB is shown in the following two images:



**Note:** These images are for reference only.


### 5.3 E1 (Indoor and outdoor unit communication error)

**Description:** The indoor unit has not received feedback from the outdoor unit for 110 seconds, four consecutive times.

**Recommended parts to prepare:**

- Indoor PCB
- Outdoor PCB
- Reactor

**Troubleshooting and repair:**



---

**Remarks:**

- Use a multimeter to test the resistance of the reactor which does not connect with capacitor.
- The normal value should be around zero ohm. Otherwise, the reactor must have malfunction.




## 5.4 E3/F5(Fan speed is operating outside of the normal range)

**Description:** When the indoor fan speed keeps too low (300RPM) for certain time, the unit will stop and the LED will display the failure(E3). When the outdoor fan speed registers below 200RPM or over 1500RPM for an extended period of time, the unit will stop and the LED will display the failure(F5).

### Recommended parts to prepare:

- Wiring mistake
- Faulty fan assembly's faulty
- Faulty fan motor
- Faulty PCB

### Troubleshooting and repair:




## Index:

### 1. Indoor or Outdoor DC Fan Motor(control chip is in fan motor)

Power on and when the unit is in standby, measure the voltage of pin1-pin3, pin4-pin3 in fan motor connector. If the value of the voltage is not in the range showing in below table, the PCB must has problems and need to be replaced.


- DC motor voltage input and output (voltage: 220-240V~):

| No. | Color  | Signal | Voltage   |
|-----|--------|--------|-----------|
| 1   | Red    | Vs/Vm  | 280V~380V |
| 2   | ---    | ---    | ---       |
| 3   | Black  | GND    | 0V        |
| 4   | White  | Vcc    | 14-17.5V  |
| 5   | Yellow | Vsp    | 0~5.6V    |
| 6   | Blue   | FG     | 14-17.5V  |




### 2. Outdoor DC Fan Motor (control chip is in outdoor PCB)

Release the UVW connector. Measure the resistance of U-V, U-W, V-W. If the resistance is not equal to each other, the fan motor must has problems and need to be replaced. otherwise the PCB must has problems and need to be replaced.



### 3. Indoor AC Fan Motor

Power on and set the unit running in fan mode at high fan speed. After running for 15 seconds, measure the voltage of pin1 and pin2. If the value of the voltage is less than 100V(208~240V power supply) or 50V(115V power supply), the PCB must has problems and need to be replaced.





## 5.5 E4/E5/F1/F2/F3 (Open circuit or short circuit of temperature sensor diagnosis and solution)

**Description:** If the sampling voltage is lower than 0.06V or higher than 4.94V, the LED will display the failure.

**Recommended parts to prepare:**

- Wiring mistake
- Faulty sensor
- Faulty PCB

**Troubleshooting and repair:**




## 5.6 E7 (Indoor PCB /Display board communication error)

**Description:** Indoor PCB does not receive feedback from Display board for 120 seconds.

### Recommended parts to prepare:

- Wiring mistake
- Faulty PCB
- Display board malfunction

### Troubleshooting and repair:





## 5.7 EC (Refrigerant Leakage Detection diagnosis and solution)


**Description:** Define the evaporator coil temp. T2 of the compressor just starts running as Tcool.

In the beginning 8 minutes after the compressor starts up, if  $T2 < T_{cool} - 2^{\circ}\text{C}$  does not keep continuous 4 seconds and compressor running frequency higher than 50Hz does not keep continuous 3 minutes, and this situation happens 3 times, the display area will show "EC" and AC will turn off.

### Recommended parts to prepare:

- Faulty T2 sensor
- Faulty indoor PCB
- System problems, such as leakage or blockages

### Troubleshooting and repair:




## 5.8 F0(Overload current protection diagnosis and solution)

**Description:** An abnormal current rise is detected by checking the specified current detection circuit.

### Recommended parts to prepare:

- Power supply problems.
- System blockage
- Faulty PCB
- Wiring mistake
- Compressor malfunction

### Troubleshooting and repair:




## 5.9 P0(IPM malfunction or IGBT over-strong current protection diagnosis and solution)

**Description:** When the voltage signal the IPM sends to the compressor drive chip is abnormal, the display LED shows “P0” and the AC turn off.

### Recommended parts to prepare:

- Wiring mistake
- IPM malfunction
- Faulty outdoor fan assembly
- Compressor malfunction
- Faulty outdoor PCB

### Troubleshooting and repair:




## 5.10 P1(Over voltage or too low voltage protection diagnosis and solution)

**Description:** Abnormal increases or decreases in voltage are detected by checking the specified voltage detection circuit.

### Recommended parts to prepare:

- Power supply issues
- System leakage or blockage
- Faulty PCB

### Troubleshooting and repair:



---


## 5.11 P2(High temperature protection of IPM module diagnosis and solution)

**Description:** If the temperature of IPM module is higher than setting value, the LED displays this failure code.

**Recommended parts to prepare:**

- Faulty PCB
- Connection problems

**Troubleshooting and repair:**




## 5.12 P4(Inverter compressor drive error diagnosis and solution)

**Description:** An abnormal inverter compressor drive is detected by a special detection circuit, including communication signal detection, voltage detection, compressor rotation speed signal detection and so on.

### Recommended parts to prepare:

- Wiring mistake
- PM malfunction
- Outdoor fan ass'y faulty
- Compressor malfunction
- Outdoor PCB faulty

### Troubleshooting and repair:



---



# **Contents**

- i) Temperature Sensor Resistance Value Table for T1, T2, T3, and T4 (°C – K) ....83**
- ii) Temperature Sensor Resistance Value Table for TP (°C – K).....84**

**i) Temperature Sensor Resistance Value Table for T1,T2,T3 and T4 (°C – K)**

| °C  | °F | K Ohm   | °C | °F  | K Ohm   | °C | °F  | K Ohm   | °C  | °F  | K Ohm   |
|-----|----|---------|----|-----|---------|----|-----|---------|-----|-----|---------|
| -20 | -4 | 115.266 | 20 | 68  | 12.6431 | 60 | 140 | 2.35774 | 100 | 212 | 0.62973 |
| -19 | -2 | 108.146 | 21 | 70  | 12.0561 | 61 | 142 | 2.27249 | 101 | 214 | 0.61148 |
| -18 | 0  | 101.517 | 22 | 72  | 11.5    | 62 | 144 | 2.19073 | 102 | 216 | 0.59386 |
| -17 | 1  | 96.3423 | 23 | 73  | 10.9731 | 63 | 145 | 2.11241 | 103 | 217 | 0.57683 |
| -16 | 3  | 89.5865 | 24 | 75  | 10.4736 | 64 | 147 | 2.03732 | 104 | 219 | 0.56038 |
| -15 | 5  | 84.219  | 25 | 77  | 10      | 65 | 149 | 1.96532 | 105 | 221 | 0.54448 |
| -14 | 7  | 79.311  | 26 | 79  | 9.55074 | 66 | 151 | 1.89627 | 106 | 223 | 0.52912 |
| -13 | 9  | 74.536  | 27 | 81  | 9.12445 | 67 | 153 | 1.83003 | 107 | 225 | 0.51426 |
| -12 | 10 | 70.1698 | 28 | 82  | 8.71983 | 68 | 154 | 1.76647 | 108 | 226 | 0.49989 |
| -11 | 12 | 66.0898 | 29 | 84  | 8.33566 | 69 | 156 | 1.70547 | 109 | 228 | 0.486   |
| -10 | 14 | 62.2756 | 30 | 86  | 7.97078 | 70 | 158 | 1.64691 | 110 | 230 | 0.47256 |
| -9  | 16 | 58.7079 | 31 | 88  | 7.62411 | 71 | 160 | 1.59068 | 111 | 232 | 0.45957 |
| -8  | 18 | 56.3694 | 32 | 90  | 7.29464 | 72 | 162 | 1.53668 | 112 | 234 | 0.44699 |
| -7  | 19 | 52.2438 | 33 | 91  | 6.98142 | 73 | 163 | 1.48481 | 113 | 235 | 0.43482 |
| -6  | 21 | 49.3161 | 34 | 93  | 6.68355 | 74 | 165 | 1.43498 | 114 | 237 | 0.42304 |
| -5  | 23 | 46.5725 | 35 | 95  | 6.40021 | 75 | 167 | 1.38703 | 115 | 239 | 0.41164 |
| -4  | 25 | 44      | 36 | 97  | 6.13059 | 76 | 169 | 1.34105 | 116 | 241 | 0.4006  |
| -3  | 27 | 41.5878 | 37 | 99  | 5.87359 | 77 | 171 | 1.29078 | 117 | 243 | 0.38991 |
| -2  | 28 | 39.8239 | 38 | 100 | 5.62961 | 78 | 172 | 1.25423 | 118 | 244 | 0.37956 |
| -1  | 30 | 37.1988 | 39 | 102 | 5.39689 | 79 | 174 | 1.2133  | 119 | 246 | 0.36954 |
| 0   | 32 | 35.2024 | 40 | 104 | 5.17519 | 80 | 176 | 1.17393 | 120 | 248 | 0.35982 |
| 1   | 34 | 33.3269 | 41 | 106 | 4.96392 | 81 | 178 | 1.13604 | 121 | 250 | 0.35042 |
| 2   | 36 | 31.5635 | 42 | 108 | 4.76253 | 82 | 180 | 1.09958 | 122 | 252 | 0.3413  |
| 3   | 37 | 29.9058 | 43 | 109 | 4.5705  | 83 | 181 | 1.06448 | 123 | 253 | 0.33246 |
| 4   | 39 | 28.3459 | 44 | 111 | 4.38736 | 84 | 183 | 1.03069 | 124 | 255 | 0.3239  |
| 5   | 41 | 26.8778 | 45 | 113 | 4.21263 | 85 | 185 | 0.99815 | 125 | 257 | 0.31559 |
| 6   | 43 | 25.4954 | 46 | 115 | 4.04589 | 86 | 187 | 0.96681 | 126 | 259 | 0.30754 |
| 7   | 45 | 24.1932 | 47 | 117 | 3.88673 | 87 | 189 | 0.93662 | 127 | 261 | 0.29974 |
| 8   | 46 | 22.5662 | 48 | 118 | 3.73476 | 88 | 190 | 0.90753 | 128 | 262 | 0.29216 |
| 9   | 48 | 21.8094 | 49 | 120 | 3.58962 | 89 | 192 | 0.8795  | 129 | 264 | 0.28482 |
| 10  | 50 | 20.7184 | 50 | 122 | 3.45097 | 90 | 194 | 0.85248 | 130 | 266 | 0.2777  |
| 11  | 52 | 19.6891 | 51 | 124 | 3.31847 | 91 | 196 | 0.82643 | 131 | 268 | 0.27078 |
| 12  | 54 | 18.7177 | 52 | 126 | 3.19183 | 92 | 198 | 0.80132 | 132 | 270 | 0.26408 |
| 13  | 55 | 17.8005 | 53 | 127 | 3.07075 | 93 | 199 | 0.77709 | 133 | 271 | 0.25757 |
| 14  | 57 | 16.9341 | 54 | 129 | 2.95896 | 94 | 201 | 0.75373 | 134 | 273 | 0.25125 |
| 15  | 59 | 16.1156 | 55 | 131 | 2.84421 | 95 | 203 | 0.73119 | 135 | 275 | 0.24512 |
| 16  | 61 | 15.3418 | 56 | 133 | 2.73823 | 96 | 205 | 0.70944 | 136 | 277 | 0.23916 |
| 17  | 63 | 14.6181 | 57 | 135 | 2.63682 | 97 | 207 | 0.68844 | 137 | 279 | 0.23338 |
| 18  | 64 | 13.918  | 58 | 136 | 2.53973 | 98 | 208 | 0.66818 | 138 | 280 | 0.22776 |
| 19  | 66 | 13.2631 | 59 | 138 | 2.44677 | 99 | 210 | 0.64862 | 139 | 282 | 0.22231 |



## ii) Temperature Sensor Resistance Value Table for TP (°C – K)

| °C  | °F | K Ohm | °C | °F  | K Ohm | °C | °F  | K Ohm | °C  | °F  | K Ohm |
|-----|----|-------|----|-----|-------|----|-----|-------|-----|-----|-------|
| -20 | -4 | 542.7 | 20 | 68  | 68.66 | 60 | 140 | 13.59 | 100 | 212 | 3.702 |
| -19 | -2 | 511.9 | 21 | 70  | 65.62 | 61 | 142 | 13.11 | 101 | 214 | 3.595 |
| -18 | 0  | 483   | 22 | 72  | 62.73 | 62 | 144 | 12.65 | 102 | 216 | 3.492 |
| -17 | 1  | 455.9 | 23 | 73  | 59.98 | 63 | 145 | 12.21 | 103 | 217 | 3.392 |
| -16 | 3  | 430.5 | 24 | 75  | 57.37 | 64 | 147 | 11.79 | 104 | 219 | 3.296 |
| -15 | 5  | 406.7 | 25 | 77  | 54.89 | 65 | 149 | 11.38 | 105 | 221 | 3.203 |
| -14 | 7  | 384.3 | 26 | 79  | 52.53 | 66 | 151 | 10.99 | 106 | 223 | 3.113 |
| -13 | 9  | 363.3 | 27 | 81  | 50.28 | 67 | 153 | 10.61 | 107 | 225 | 3.025 |
| -12 | 10 | 343.6 | 28 | 82  | 48.14 | 68 | 154 | 10.25 | 108 | 226 | 2.941 |
| -11 | 12 | 325.1 | 29 | 84  | 46.11 | 69 | 156 | 9.902 | 109 | 228 | 2.86  |
| -10 | 14 | 307.7 | 30 | 86  | 44.17 | 70 | 158 | 9.569 | 110 | 230 | 2.781 |
| -9  | 16 | 291.3 | 31 | 88  | 42.33 | 71 | 160 | 9.248 | 111 | 232 | 2.704 |
| -8  | 18 | 275.9 | 32 | 90  | 40.57 | 72 | 162 | 8.94  | 112 | 234 | 2.63  |
| -7  | 19 | 261.4 | 33 | 91  | 38.89 | 73 | 163 | 8.643 | 113 | 235 | 2.559 |
| -6  | 21 | 247.8 | 34 | 93  | 37.3  | 74 | 165 | 8.358 | 114 | 237 | 2.489 |
| -5  | 23 | 234.9 | 35 | 95  | 35.78 | 75 | 167 | 8.084 | 115 | 239 | 2.422 |
| -4  | 25 | 222.8 | 36 | 97  | 34.32 | 76 | 169 | 7.82  | 116 | 241 | 2.357 |
| -3  | 27 | 211.4 | 37 | 99  | 32.94 | 77 | 171 | 7.566 | 117 | 243 | 2.294 |
| -2  | 28 | 200.7 | 38 | 100 | 31.62 | 78 | 172 | 7.321 | 118 | 244 | 2.233 |
| -1  | 30 | 190.5 | 39 | 102 | 30.36 | 79 | 174 | 7.086 | 119 | 246 | 2.174 |
| 0   | 32 | 180.9 | 40 | 104 | 29.15 | 80 | 176 | 6.859 | 120 | 248 | 2.117 |
| 1   | 34 | 171.9 | 41 | 106 | 28    | 81 | 178 | 6.641 | 121 | 250 | 2.061 |
| 2   | 36 | 163.3 | 42 | 108 | 26.9  | 82 | 180 | 6.43  | 122 | 252 | 2.007 |
| 3   | 37 | 155.2 | 43 | 109 | 25.86 | 83 | 181 | 6.228 | 123 | 253 | 1.955 |
| 4   | 39 | 147.6 | 44 | 111 | 24.85 | 84 | 183 | 6.033 | 124 | 255 | 1.905 |
| 5   | 41 | 140.4 | 45 | 113 | 23.89 | 85 | 185 | 5.844 | 125 | 257 | 1.856 |
| 6   | 43 | 133.5 | 46 | 115 | 22.89 | 86 | 187 | 5.663 | 126 | 259 | 1.808 |
| 7   | 45 | 127.1 | 47 | 117 | 22.1  | 87 | 189 | 5.488 | 127 | 261 | 1.762 |
| 8   | 46 | 121   | 48 | 118 | 21.26 | 88 | 190 | 5.32  | 128 | 262 | 1.717 |
| 9   | 48 | 115.2 | 49 | 120 | 20.46 | 89 | 192 | 5.157 | 129 | 264 | 1.674 |
| 10  | 50 | 109.8 | 50 | 122 | 19.69 | 90 | 194 | 5     | 130 | 266 | 1.632 |
| 11  | 52 | 104.6 | 51 | 124 | 18.96 | 91 | 196 | 4.849 |     |     |       |
| 12  | 54 | 99.69 | 52 | 126 | 18.26 | 92 | 198 | 4.703 |     |     |       |
| 13  | 55 | 95.05 | 53 | 127 | 17.58 | 93 | 199 | 4.562 |     |     |       |
| 14  | 57 | 90.66 | 54 | 129 | 16.94 | 94 | 201 | 4.426 |     |     |       |
| 15  | 59 | 86.49 | 55 | 131 | 16.32 | 95 | 203 | 4.294 |     |     |       |
| 16  | 61 | 82.54 | 56 | 133 | 15.73 | 96 | 205 | 4.167 |     |     |       |
| 17  | 63 | 78.79 | 57 | 135 | 15.16 | 97 | 207 | 4.045 |     |     |       |
| 18  | 64 | 75.24 | 58 | 136 | 14.62 | 98 | 208 | 3.927 |     |     |       |
| 19  | 66 | 71.86 | 59 | 138 | 14.09 | 99 | 210 | 3.812 |     |     |       |